



**CARGOLOCK**

*INSTALLATION INSTRUCTIONS*

**SPRINTER**

**PLEASE READ AND FOLLOW  
THESE INSTRUCTIONS**

## DEADBOLT - REAR DOOR

- 1 Tape the **REAR DOOR BRACKET TEMPLATE** to the inside of the right rear door as shown in Fig. 1.
- 2 Carefully mark the hole locations with a center punch and drill holes as indicated on the template.
- 3 Tape the **DOOR JAMB TEMPLATE** to the door as shown in Fig. 2.
- 4 Mark the hole location with a center punch. Drill a 1/4" pilot hole and then enlarge it with a step drill to 3/4". This will insure a clean and accurate hole.
- 5 Install the deadbolt assembly inside the door and fasten it in place with four 1/4"x20 washerhead screws as shown in Fig. 3.




Fig. 1



Fig. 2




Fig. 3

## DEADBOLT - REAR DOOR

continued

- 7 Check the operation of the deadbolt assembly. Be sure it slides freely through the 3/4" door jamb hole. If the deadbolt rubs or binds against the 3/4" hole enlarge the hole with a metal file.
- 8 Install the square TRIM PLATE over the door jamb hole as shown in Fig. 2. Use a 1/8" drill.
- 9 The next step is to locate and fasten the strike plate on the opposite door jamb as shown in Fig. 1. Close both doors completely, and then peel off the adhesive backing on the strike plate and place it into position as shown in Fig. 1.
- 10 Open the doors and fasten the strike plate with the provided sheet metal screws. Do not use any screws other than the ones provided as they will make contact with the latch mechanism inside the door!
- 11 Use the rear door template to cut a slot in the door panel for the manual release knob.
- 12 Install the door panel and trimplate as shown in Fig. 2.



Fig. 1



Fig. 2

## DEADBOLT-SLIDING DOOR

- 1 Place the mounting bracket for the deadbolt assembly into position and fasten it in place with four self drilling screws as shown in Fig. 1.
- 2 Install the deadbolt assembly on the mounting bracket and fasten it in place with four washer head hex nuts as shown in Fig. 2.
- 3 Close the sliding door and position the strike plate on the sliding door as shown in Fig. 3.
- 4 Fasten the strike plate to the sliding door with the sheet metal screws provided.
- 5 Install the cover on the deadbolt assembly as shown in Fig. 4.
- 6 Install the manual release knob.



Fig. 1




Fig. 2



Fig. 3



Fig. 4

## DEADBOLT-SLIDING DOOR-DRIVERS SIDE

- 1 Place the mounting bracket for the deadbolt assembly into position and fasten it in place with four self drilling screws as shown in Fig. 1.
- 2 Install the deadbolt assembly on the mounting bracket and fasten it in place with four washer head hex nuts as shown in Fig. 2.
- 3 Close the sliding door and position the strike plate on the sliding door as shown in Fig. 3.
- 4 Fasten the strike plate to the sliding door with the sheet metal screws provided.
- 5 Install the cover on the deadbolt assembly as shown in Fig. 4.
- 6 Install the manual release knob.



Fig. 1




Fig. 2



Fig. 3



Fig. 4